

How to attach a Lotion Pump to a Pail lid



Step 1: Disassemble the Pump. Listed left to right, there is the plunger assembly, the 38mm cap adapter, and the threaded section of the Pump.



Step 2: Trace around the threaded section of the Pump on the top of the pail lid



Step 3: Use a utility knife to cut out the inside of the circle that was just traced. Be sure to cut along the inside of the trace mark.



Step 4: Insert the threaded section of the Pump into the underside of the pail lid thru the hole just cut.



Step 5: Turn Lid over and screw on the plunger assembly of the Pump minus the 38mm cap adapter onto the threaded section above the pail lid.

Step 6: Reattach the lid to you pail. Then you may dispense your material.